










# A guide to setup your Bell and start your Backyard Dreams




## PACKING LIST







-  (A) **1x TENT**
-  (B) **1x CENTER POLE**
-  (C) **1x A-FRAME**
-  (D) **1x COLOURED CARABINER + GUYLINE**
-  (E) **CARABINER + GUYLINE**  
**12x BELL 4.4**  
**12x BELL 5.2**
-  (F) **PEG**  
**13x BELL 4.4**  
**13x BELL 5.2**
-  (G) **T-PEG**  
**13x BELL 4.4**  
**13x BELL 5.2**
-  (H) **1x HAMMER**

|                | TENT | TENT + GUYLINES |
|----------------|------|-----------------|
| LARGE BELL 4.4 | 4,4m | Ø 9,0m          |
| MAJOR BELL 5.2 | 5,2m | Ø 10,6m         |



LARGE BELL 4.4  
MAJOR BELL 5.2





1 a m



AUTENTIC

### HOW TO TENSION

Do not over tension the guy-ropes.

They are tent ropes, no quiter strings

It may hinder opening/closing the door.

