


SETUP INSTRUCTIONS




AUTENTIC.world

PACKING LIST



Ⓐ 1x Inner liner




10 min.




Release the tension on the guylines and take the centerpole out of the tent.

1




Unroll your innerliner. Make sure the D-rings on the top are on the inside of the tent.

2




Orient the door and attach the hooks to the corresponding loops of the tent.

3




Place the centerpole back in the tent.


4



Attach the metal hooks to the corresponding O-ring of the tent.
+ tension back the guylines



Is the Innerliner too loose?
Adjust the length of the elastic at the knot.



Use the D-rings to hang up a light or deco in the tent.