






PACKING LIST




1




Release the tension on the guylines and remove the center pole. Unroll the inner liner and make sure that the D rings are positioned inside the tent. the center pole out of the tent.

2




Align the opening of the inner liner with the door of the tent and connect the hooks of the inner liner to the corresponding loops inside the tent.

3




Place the center pole back into the tent, making sure it fits into the black top loop of the inner liner.


4



Attach the metal hooks to the corresponding O-ring of the tent and tighten the guylines.



Is the Inner liner too loose?
Adjust the length of the elastic at the knot.



Optional
Use the D-rings at the top of the inner liner to hang a light, or other small decoration inside the tent.